

Glossary

BATHS - a lag container which is filled with preservative liquid; an act or process of immersing timber pieces in a large container of preservative liquids

CHARRING - partially burning of timber so as to blacken its surface

IMMERSION - the action of immersing timber in a liquid (preservative liquid)

LEACHING - when the soluble chemical in the preservative applied on the timber is drained away by the action of percolating liquid, especially rainwater.